

# Tanita Scale Installation Procedure

1. Unplug cord and power cord from digital display.
2. Remove pad
3. Remove the 4 bolts
4. Carefully remove the white top
5. Remove drawers to reach the bolts holding the scale to the table.
6. To remove the drawers:
  - a. Open drawers. Depress plastic latch on drawer glide on both sides while pulling outward slightly on drawer. The entire drawer box will come out.
7. Locate 4 bolts underneath the table. Remove them.
8. Unplug the scale from the wire going to the display unit. Leave the screw intact. Use the same wire for new scale. Remove the scale.
9. Place the new scale on table with the up side up. Line up the holes. Replace the 4 bolts.
10. Plug in scale. Replace white top. Secure 4 bolts and washers. Replace pad.

\* For technical support call **888-386-8225**

